

Запчасти для двигателей EX

Техническое описание

Архангельск (8182)63-90-72
Астана (7172)727-132
Астрахань (8512)99-46-04
Барнаул (3852)73-04-60
Белгород (4722)40-23-64
Брянск (4832)59-03-52
Владивосток (423)249-28-31
Волгоград (844)278-03-48
Вологда (8172)26-41-59
Воронеж (473)204-51-73
Екатеринбург (343)384-55-89

Иваново (4932)77-34-06
Ижевск (3412)26-03-58
Иркутск (395)279-98-46
Казань (843)206-01-48
Калининград (4012)72-03-81
Калуга (4842)92-23-67
Кемерово (3842)65-04-62
Киров (8332)68-02-04
Краснодар (861)203-40-90
Красноярск (391)204-63-61
Курск (4712)77-13-04
Липецк (4742)52-20-81

Магнитогорск (3519)55-03-13
Москва (495)268-04-70
Мурманск (8152)59-64-93
Набережные Челны (8552)20-53-41
Новокузнецк (3843)20-46-81
Новосибирск (383)227-86-73
Омск (3812)21-46-40
Орел (4862)44-53-42
Оренбург (3532)37-68-04
Пенза (8412)22-31-16

Пермь (342)205-81-47
Ростов-на-Дону (863)308-18-15
Рязань (4912)46-61-64
Самара (846)206-03-16
Санкт-Петербург (812)309-46-40
Саратов (845)249-38-78
Севастополь (8692)22-31-93
Симферополь (3652)67-13-56
Смоленск (4812)29-41-54
Сочи (862)225-72-31
Ставрополь (8652)20-65-13

Сургут (3462)77-98-35
Тверь (4822)63-31-35
Томск (3822)98-41-53
Тула (4872)74-02-29
Тюмень (3452)66-21-18
Ульяновск (8422)24-23-59
Уфа (347)229-48-12
Хабаровск (4212)92-98-04
Челябинск (351)202-03-61
Череповец (8202)49-02-64
Ярославль (4852)69-52-93


Киргизия (996)312-96-26-47 Казахстан (772)734-952-31 Таджикистан (992)427-82-92-69

<http://robinsubaru.nt-rt.ru> || rbb@nt-rt.ru


Картер двигателя EX13

№	Артикул	Наименование
10	276-10102-41	картер двигателя EX13,W/OIL SENSOR
20	237-14202-03	направляющая клапана
26	277-16010-01	сальник клапана
30	044-02501-80	сальник коленвала
40	060-02800-21	подшипник коленвала
50	277-15011-03	направляющая втулка
60	010-50802-50	шпилька
70	010-50603-51	шпилька
75	044-00600-20	сальник вала регулятора
80	040-11400-30	сливная пробка
90	021-11400-20	прокладка с.п.
210	277-11002-21	крышка главного подшипника
220	044-02502-10	сальник коленвала
230	060-02501-40	подшипник коленвала
250	277-45004-J1	шестерня регулятора
260	205-41901-03	ось шестерни регулятора
270	277-63601-23	масляный щуп
270	277-63601-30	масляный щуп
275	277-65001-03	пробка заливной горловины
280	021-31600-20	прокладка щупа
281	021-31600-20	прокладка пробки 3.Г..
300	001-04083-50	болт крышки гл.подшипника
610	276-13001-11	головка цилиндра (ГБЦ) EX13,Old Style
620	276-15001-13	прокладка ГБЦ T=0.2
620	276-15001-33	прокладка ГБЦ T=0.2
630	011-00802-40	болт ГБЦ

631	001-00803-10	болт
680	277-15503-01	клапанная крышка
690	277-16001-13	прокладка клапанной крышки
700	277-15011-03	направляющая втулка
710	011-00600-20	болт к.к.
	276-99001-27	набор прокладок




Коленчатый вал и поршень EX13




№	Артикул	Наименование
10	276-20901-41	коленвал EX13-3/4"key,5/16tap
10	276-21001-21	коленвал EX13-5/8"Pump
10	276-21201-21	коленвал EX13-SAE Taper
50	018-01400-20	гайка коленвала
70	032-30300-10	шпонка
310	276-22501-10	шатун в сборе EX13-STD
310	276-22502-00	шатун в сборе EX13-Undersize 025mm
320	277-23001-03	болт крышки шатуна
350	276-23301-13	поршневой палец 13DX9DX44L
23501-17		поршневые EX13-STD
371	276-23502-17	кольца поршневые EX13-0.25mm
372	276-23503-17	кольца поршневые EX13-0.50mm
380	215-25004-03	стопорное кольцо
360	276-23401-H3	поршень EX13-STD.(58DX35H)
361	276-23403-H3	поршень EX13-0.25mm
362	276-23404-H3	поршень EX13-0.50mm
370	276-	кольца


Глушитель, воздушный фильтр EX13




URETHANE FOAM



DUAL ELEMENT



PRE CLEANER




№	Артикул	Наименование
10	277-31601-31	Шестерня распредела
25	277-35101-03	ось распредела
27	024-00600-10	стопор
34	277-38601-03	ось пружины
35	277-36401-03	стопор
37	277-36501-03	шайба
38	277-38702-03	пружина
60	279-33601-03	пружина клапана
70	269-33701-03	чашка клапана
80	276-33401-Н3	впускной клапан
80	276-33401-33	впускной клапан
90	276-33501-Н3	выпускной клапан
90	276-	выпускной

	33501-33	клапан	310	276-30101-J1	глушитель
95	132-10KA0-31	фиксатор клапана	320	276-34201-01	крышка глушителя
150	276-35601-11	цепь ГРМ	340	277-35201-13	прокладка глушителя
160	277-36911-03	натяжитель цепи	350	980-20082-80	гайка
163	277-37101-03	пружина натяжителя	360	015-20600-90	болт
166	277-36902-03	ось натяжителя	361	011-00600-10	болт
170	277-36913-13	успокоитель цепи	365	011-00803-20	болт
200	277-35002-01	ось рокера	387	015-00400-60	болт крепления дефлектора
202	003-13050-00	стопорное кольцо	440	277-37001-N1	дефлектор
220	277-36201-00	рокер впускного клапана	540	277-32902-J1	изолятор
225	277-36202-00	рокер выпускного клапана	550	277-35903-J3	прокладка изолятора
230	014-90500-20	рег. винт рокера	570	002-38060-00	гайка
240	017-00500-30	контргайка Р.В.	580	011-00600-50	болт
290	011-00600-20	болт	580	011-	болт

50

510	277- 32611- 10	воздушный фильтр в сборе Foam
510	277- 32615- 20	воздушный фильтр в сборе DUAL
-200	277- 32601- 18	нижняя часть к.фильтра Foam
-200	277- 32630- 18	нижняя часть к.фильтра DUAL
-210	277- 32610- 08	уплотнитель Ф.Э. DUAL
-220	277- 32604- 08	уплотнитель К.Ф.
-250	277- 32640- 08	крышка К.Ф.
-270	277- 32741- 18	гайка
-270	277- 32741- 08	гайка
-272	277- 32607- 08	гайка
-520	277- 32603- 08	фильтрующий элемент Foam
-520	277- 32611- 07	фильтрующий элемент DUAL


Механизм акселератора EX13




№	Артикул	Наименование
10	277-42301-40	рычаг вала регулятора
20	277-42201-33	вал регулятора
30	279-42701-11	тяги
40	277-42801-23	пружина регулятора
50	003-13050-00	стопор
60	013-00602-40	болт
18	018-60600-20	гайка
80	277-42510-13	пружина
310	277-43303-01	рычаг регулятора
322	277-43701-01	связующий стержень
340	277-43502-03	ограничитель регулятора
350	277-44501-03	фиксирующая шайба
355	021-	фрикционная

	70600-70	шайба
360	004-31062-50	регулируемый болт
365	237-45004-23	пружина
395	277-43902-03	фиксатор троса
396	013-10500-30	болт Ф.Т.
435	277-46002-01	платформа регулятора
440	004-31040-80	болт
450	002-35060-00	гайка
480	267-45101-03	пружина
485	011-00600-20	болт

Охлаждение и стартер EX13




RESIN



-6	227-50131-08	фрикционная пружина
-7	227-50135-08	возвратная пружина
-8	270-50261-08	направляющая трещ
-11	268-50145-18	стакан стартера
-49	227-50152-08	болт


№	Артикул	Наименование
10	276-51201-01	корпус вентилятора Yellow
40	011-00600-30	болт
60	277-52711-21	дроссель
61	277-52702-03	защита цилиндра
80	001-04061-60	болт
81	011-00600-20	болт
220	011-00600-10	болт
210	268-50201-30	стартер обратный
-1	270-50115-08	спиральная пружина
-2	269-50120-08	шкив
-3	282-50111-18	шнур
-4	261-50100-08	ручка стартера
-5	270-50125-08	трещотка

Топливоснабжение EX13




№	Артикул	Наименование
10	276-60101-11	топливный бак EX13, 2.7L — Yellow
30	043-04400-50	крышка Т.Б.
40	X64-13600-10	сетка топливная
48	050-51200-20	топливный фильтр
48	X50-51200-20	топливный фильтр
60	002-38060-00	гайка
63	011-00601-30	болт
70	276-62603-11	топливная труба
90	056-11000-30	зажим Т.Т.
224	277-43801-01	рычаг крана

Карбюратор EX13



№	Артикул	Наименование
210	276-62301-30	Карбюратор EX13 -Foam
210	276-62302-30	Карбюратор EX13 — Dual Element
210	276-62304-40	Карбюратор EX13 — Low Profile
210	276-62312-00	Карбюратор EX13 — DE Specifications
-1	106-62538-08	дроссельная заслонка
-2	209-62351-08	ВИНТ
-3	277-62525-08	воздушная заслонка Foam, Dual
-3	277-62527-08	воздушная заслонка Low Profile
-5	246-62420-08	жиклер холостого хода
-8	277-62520-08	вал воздушной заслонки Foam, Dual
-8	277-62520-08	вал воздушной заслонки Low Profile
-11	276-62530-18	вал дроссельной заслонки Foam
-11	276-	вал

	62531-18	дроссельной заслонки EX13-Dual,Low Profile	-41	283-62357-08	пружина
-12	227-62451-08	болт	-44	207-62410-08	воздушный жиклёр
-14	277-62500-08	игольчатый клапан	-45	106-62410-08	воздушный жиклёр
-15	277-62515-08	ось поплавка	-62	236-62680-08	манжет
-16	277-62506-08	поплавковая камера	-79	236-62541-08	уплотнитель
-17	214-62450-08	уплотнительная шайба	-102	246-62390-08	манжет
-18	214-62540-08	уплотнительное кольцо	-144	277-62553-08	гайка
-19	226-62506-08	поплавок	-300	279-62103-20	топливный кран
-20	276-62440-08	главный топливный жиклёр	-302	277-62110-18	уплотнитель
-22	277-62404-18	главный жиклёр Foam,Low Profile	-303	277-62100-18	отстойник
-22	252-62405-08	главный жиклёр Dual	-325	277-62552-08	топливный манжет
-24	226-62701-08	стопор	-327	165-62377-08	винт
-28	277-62360-08	пробка поплавковой камеры			
-40	106-62556-	регулировочный винт			




№	Артикул	Наименование
10	276-79230-21	маховое колесо EX13 — STD
11	277-79431-11	катушка зажигания MARK BM3790
30	001-14062-50	болт
50	277-73101-H1	привод датчика мас.
70	015-00400-90	винт (саморез)
100	065-01401-50	свеча зажигания NGK BR6HS
110	065-50002-70	колпачок свечи зажигания
700	277-76301-21	масляный датчик
705	KU3-11071-01	выключатель
740	001-14061-60	болт
780	056-90000-20	зажим проводов


Картер двигателя EX17

№	Артикул	Наименование
10	277-10102-41	картер двигателя EX17,W/OIL SENSOR
20	237-14202-03	направляющая клапана
26	277-16010-01	сальник клапана
30	044-02501-80	сальник коленвала
40	060-02800-21	подшипник коленвала
50	277-15011-03	направляющая втулка
60	010-50802-50	шпилька
70	010-50603-51	шпилька
75	044-00600-20	сальник вала регулятора
80	040-11400-30	сливная пробка
90	021-11400-20	прокладка с.п.
210	277-11002-21	крышка главного подшипника
220	044-02502-10	сальник коленвала
230	060-02501-40	подшипник коленвала
250	277-45004-J1	шестерня регулятора
260	205-41901-03	ось шестерни регулятора
270	277-63601-23	масляный щуп
270	277-63601-30	масляный щуп
275	277-65001-03	пробка заливной горловины
280	021-31600-20	прокладка щупа
281	021-31600-20	прокладка пробки З.Г..
300	001-04083-50	болт крышки гл.подшипника
610	277-13001-11	головка цилиндра (ГБЦ) EX17,Old Style
620	277-15001-23	прокладка ГБЦ
630	011-00802-40	болт ГБЦ
631	001-00803-10	болт

- | | | |
|-----|--------------|----------------------------|
| 680 | 277-15503-01 | клапанная крышка |
| 690 | 277-16001-13 | прокладка клапанной крышки |
| 700 | 277-15011-03 | направляющая втулка |
| 710 | 011-00600-20 | болт к.к. |
| | 277-99001-27 | набор прокладок |
| | 277-99001-37 | набор прокладок |



Коленчатый вал и поршень EX17




№	Артикул	Наименование
10	277-20901-51	коленвал 3/4"key,5/16tap
10	277-21001-21	коленвал 5/8"Pump
10	277-21201-21	коленвал SAE Taper
50	018-01400-20	гайка коленвала
70	032-30300-10	шпонка
310	277-22501-10	шатун в сборе STD
310	277-22502-00	шатун в сборе Undersize 025mm
320	277-23001-03	болт крышки шатуна
350	277-23301-13	поршневой палец
23501-17		поршневые STD
371	277-23502-17	кольца поршневые 0.25mm
372	277-23503-17	кольца поршневые 0.50mm
380	056-51600-10	стопорное кольцо
360	277-23401-J3	поршень STD
361	277-32403-J3	поршень 0.25mm
362	277-23404-J3	поршень 0.50mm
370	277-	кольца

	36911-03	цепи	350	980-20082-80	гайка
163	277-37101-03	пружина натяжителя	360	015-20600-90	болт
166	277-36902-03	ось натяжителя	361	011-00600-10	болт
170	277-36913-13	успокоитель цепи	365	011-00803-20	болт
200	277-35002-01	ось рокера	387	015-00400-60	болт крепления дефлектора
202	003-13050-00	стопорное кольцо	440	277-37001-H1	дефлектор
220	277-36201-00	рокер впускного клапана	540	277-32902-J1	изолятор
225	277-36202-00	рокер выпускного клапана	550	277-35903-J3	прокладка изолятора
230	014-90500-20	рег. винт рокера	570	002-38060-00	гайка
240	017-00500-30	контргайка Р.В.	580	011-00600-50	болт
290	011-00600-20	болт	580	011-00600-50	болт
310	277-30101-J1	глушитель	510	277-32611-10	воздушный фильтр в сборе Foam
320	277-34201-31	крышка глушителя	510	277-32615-20	воздушный фильтр в сборе DUAL
340	277-35201-13	прокладка глушителя	-200	277-	нижняя часть

18

-200	277- 32630- 18	нижняя часть к.фильтра DUAL
-210	277- 32610- 08	уплотнитель Ф.Э. DUAL
-220	277- 32604- 08	уплотнитель К.Ф.
-250	277- 32640- 08	крышка К.Ф.
-270	277- 32741- 18	гайка
-270	277- 32741- 08	гайка
-272	277- 32607- 08	гайка
-520	277- 32603- 08	фильтрующий элемент Foam
-520	277- 32611- 07	фильтрующий элемент DUAL

Механизм акселератора EX17



№	Артикул	Наименование
---	---------	--------------

10	277-42301-40	рычаг вала регулятора
----	--------------	-----------------------

20	277-42201-33	вал регулятора
----	--------------	----------------

30	279-42701-11	тяги
----	--------------	------

30	277-42701-11	тяги
----	--------------	------

355	021-70600-70	фрикционная шайба
360	004-31062-50	регулирующий болт

40	277-42801-23	пружина регулятора
----	--------------	--------------------

365	237-45004-23	пружина
-----	--------------	---------

50	003-13050-00	стопор
----	--------------	--------

395	277-43902-03	фиксатор троса
-----	--------------	----------------

60	013-00602-40	болт
----	--------------	------

396	013-10500-30	болт Ф.Т.
-----	--------------	-----------

18	018-60600-20	гайка
----	--------------	-------

435	277-46002-01	платформа регулятора
-----	--------------	----------------------

80	277-42510-13	пружина
----	--------------	---------

440	004-31040-80	болт
-----	--------------	------

310	277-43303-01	рычаг регулятора
-----	--------------	------------------

450	002-35060-00	гайка
-----	--------------	-------

322	277-43701-01	связующий стержень
-----	--------------	--------------------


480	267-45101-03	пружина
-----	--------------	---------

340	277-43502-03	ограничитель регулятора
-----	--------------	-------------------------


485	011-00600-20	болт
-----	--------------	------

350	277-44501-03	фиксирующая шайба
-----	--------------	-------------------

Охлаждение и стартер EX17




RESIN



№	Артикул	Наименование
10	277-51201-01	корпус вентилятора Yellow
40	011-00600-30	болт
60	277-52711-21	дроссель
61	277-52702-03	защита цилиндра
80	001-04061-60	болт
81	011-00600-20	болт
220	011-00600-10	болт
210	269-50201-30	стартер обратный
-1	270-50115-08	спиральная пружина
-2	269-50120-08	шкив
-3	282-50111-18	шнур
-4	261-50100-08	ручка стартера
-5	270-50125-08	трещотка


-6	227-50131-08	фрикционная пружина
-7	227-50135-08	возвратная пружина
-8	270-50261-08	направляющая трещ
-11	269-50145-18	стакан стартера
-49	227-50152-08	болт

Топливоснабжение EX17



№	Артикул	Наименование
10	277-60101-21	топливный бак Yellow
30	043-04400-50	крышка Т.Б.
40	X64-13600-10	сетка топливная
48	050-51200-20	топливный фильтр
48	X50-51200-20	топливный фильтр
60	002-38060-00	гайка
63	011-00601-30	болт
70	277-62601-11	топливная труба
90	056-11000-30	зажим Т.Т.
224	277-43801-01	рычаг крана


Карбюратор EX17



№	Артикул	Наименование
210	277-62301-30	Карбюратор Foam
210	277-62302-30	Карбюратор Dual Element
210	277-62304-40	Карбюратор Low Profile
210	277-62303-20	Карбюратор Cyclone
-1	277-62535-08	дроссельная заслонка
-2	209-62351-08	ВИНТ
-3	277-62525-08	воздушная заслонка Foam, Dual
-3	277-62527-08	воздушная заслонка Low Profile
-5	246-62420-08	жиклер холостого хода
-8	277-62520-08	вал воздушной заслонки Foam, Dual
-8	277-62520-08	вал воздушной заслонки Low Profile
-11	277-62531-18	вал дроссельной заслонки Dual, Cyclone

-12	227- 62451- 08	болт	-41	283- 62357- 08	пружина
-14	277- 62500- 08	игольчатый клапан	-44	248- 62410- 08	воздушный жиклёр
-15	277- 62515- 08	ось поплавка	-45	106- 62410- 08	воздушный жиклёр
-16	277- 62506- 08	поплавковая камера	-62	236- 62680- 08	манжет
-17	214- 62450- 08	уплотнительная шайба	-79	236- 62541- 08	уплотнитель
-18	214- 62540- 08	уплотнительное кольцо	-102	246- 62390- 08	манжет
-19	226- 62506- 08	поплавок	-144	277- 62553- 08	гайка
-20	277- 62440- 08	главный топливный жиклёр	-300	279- 62103- 20	топливный кран
-22	277- 62402- 08	главный жиклёр Foam	-302	277- 62110- 18	уплотнитель
-22	226- 62412- 08	главный жиклёр Dual	-303	277- 62100- 18	отстойник
-22	277- 62412- 08	главный жиклёр Cyclone	-325	277- 62552- 08	топливный манжет
-24	226- 62701- 08	стопор	-327	165- 62377- 08	винт
-28	277- 62360- 08	пробка поплавковой камеры			
-40	106- 62556-	регулирующий винт			

Электрическое устройство EX17




№	Артикул	Наименование
10	277-79230-11	маховое колесо STD
11	277-79431-11	катушка зажигания MARK BM3790
30	001-14062-50	болт
50	277-73101-H1	привод датчика мас.
60	066-00004-70	выключатель
70	015-00400-90	винт (саморез)
100	065-01401-50	свеча зажигания NGK BR6HS
110	065-50002-70	колпачок свечи зажигания
700	277-76301-21	масляный датчик
705	KU3-11071-01	выключатель
740	001-14061-60	болт
780	056-90000-20	зажим проводов


Картер двигателя EX21

№	Артикул	Наименование
10	278-10102-41	картер двигателя W/OIL SENSOR
20	237-14202-03	направляющая клапана
26	277-16010-01	сальник клапана
30	044-02501-80	сальник коленвала
40	060-02800-21	подшипник коленвала
50	277-15011-03	направляющая втулка
60	010-50802-50	шпилька
70	010-50603-51	шпилька
75	044-00600-20	сальник вала регулятора
80	040-11400-30	сливная пробка
90	021-11400-20	прокладка с.п.
210	277-11002-21	крышка главного подшипника
220	044-02502-10	сальник коленвала
230	060-02501-40	подшипник коленвала
250	277-45004-J1	шестерня регулятора
260	205-41901-03	ось шестерни регулятора
270	277-63601-23	масляный щуп
270	277-63601-30	масляный щуп
275	277-65001-03	пробка заливной горловины
280	021-31600-20	прокладка щупа
281	021-31600-20	прокладка пробки З.Г..
300	001-04083-50	болт крышки гл.подшипника
610	278-13001-11	головка цилиндра (ГБЦ) Old Style
620	277-15001-23	прокладка ГБЦ
630	011-00802-40	болт ГБЦ
631	001-00803-10	болт

680	277-15503-01	клапанная крышка
690	277-16001-13	прокладка клапанной крышки
700	277-15011-03	направляющая втулка
710	011-00600-20	болт к.к.
	277-99001-27	набор прокладок
	277-99001-37	набор прокладок




Коленчатый вал и поршень EX21




371	277- 23502- 17	кольца поршневые 0.25mm
372	277- 23503- 17	кольца поршневые 0.50mm
380	056- 51600- 10	стопорное кольцо

№	Артикул	Наименование
10	278- 20901- 61	коленвал 3/4"key,5/16tap
10	278- 21001- 31	коленвал 5/8"Pump
10	278- 21201- 31	коленвал SAE Taper
50	018- 01400- 20	гайка коленвала
70	032- 30300- 10	шпонка
310	278- 22501- 10	шатун в сборе STD
310	278- 22502- 00	шатун в сборе Undersize 025mm
320	277- 23001- 03	болт крышки шатуна
350	277- 23301- 13	поршневой палец
360	277- 23401- J3	поршень STD
361	277- 32403- J3	поршень 0.25mm
362	277- 23404- J3	поршень 0.50mm
370	277- 23501- 17	кольца поршневые STD


Глушитель, воздушный фильтр EX21




URETHANE FOAM



DUAL ELEMENT



PRE CLEANER




№	Артикул	Наименование
10	277-31601-31	Шестерня распредвала
25	277-35101-03	ось распредвала
27	024-00600-10	стопор
34	277-38601-03	ось пружины
35	277-36401-03	стопор
37	277-36501-03	шайба
38	277-38702-03	пружина
60	279-33601-03	пружина клапана
70	269-33701-03	чашка клапана
80	277-33401-Н3	впускной клапан
90	277-33501-Н3	выпускной клапан
95	132-10KA0-31	фиксатор клапана
150	278-35601-11	цепь ГРМ

160	277-36911-03	натяжитель цепи	340	277-35201-13	прокладка глушителя
163	277-37101-03	пружина натяжителя	350	980-20082-80	гайка
166	277-36902-03	ось натяжителя	360	015-20600-90	болт
170	277-36913-13	успокоитель цепи	361	011-00600-10	болт
200	277-35002-01	ось рокера	365	011-00803-20	болт
202	003-13050-00	стопорное кольцо	387	015-00400-60	болт крепления дефлектора
220	277-36201-00	рокер впускного клапана	440	277-37001-H1	дефлектор
225	277-36202-00	рокер выпускного клапана	540	277-32902-J1	изолятор
230	014-90500-20	рег. винт рокера	550	277-35903-J3	прокладка изолятора
240	017-00500-30	контргайка P.B.	570	002-38060-00	гайка
290	011-00600-20	болт	580	011-00600-50	болт
310	278-30101-H1	глушитель	580	011-00600-50	болт
320	277-34201-31	крышка глушителя	510	277-32611-10	воздушный фильтр в сборе Foam
			510	277-	воздушный



	20	DUAL
-200	277- 32601- 18	нижняя часть к.фильтра Foam
-200	277- 32630- 18	нижняя часть к.фильтра DUAL
-210	277- 32610- 08	уплотнитель Ф.Э. DUAL
-220	277- 32604- 08	уплотнитель К.Ф.
-250	277- 32640- 08	крышка К.Ф.
-270	277- 32741- 18	гайка
-270	277- 32741- 08	гайка
-272	277- 32607- 08	гайка
-520	277- 32603- 08	фильтрующий элемент Foam
-520	277- 32611- 07	фильтрующий элемент DUAL

Механизм акселератора EX21




			№	Артикул	Наименование
			10	277-42301-40	рычаг вала регулятора
			20	277-42201-33	вал регулятора
			30	277-42701-11	тяга
			40	277-42801-23	пружина регулятора
360	004-31062-50	регулирующий болт	50	003-13050-00	стопор
365	237-45004-23	пружина	60	013-00602-40	болт
395	277-43902-03	фиксатор троса	18	018-60600-20	гайка
396	013-10500-30	болт Ф.Т.	80	277-42510-13	пружина
435	277-46002-01	платформа регулятора	310	277-43303-01	рычаг регулятора
440	004-31040-80	болт	322	277-43701-01	связующий стержень
450	002-35060-00	гайка	340	277-43502-03	ограничитель регулятора
480	267-45101-03	пружина	350	277-44501-03	фиксирующая шайба
485	011-00600-20	болт	355	021-70600-70	фрикционная шайба

Охлаждение и стартер EX21




RESIN



-5	270-50125-08	трещотка
-6	227-50131-08	фрикционная пружина
-7	227-50135-08	возвратная пружина
-8	270-50261-08	направляющая трещ
-11	278-50145-18	стакан стартера
-49	227-50152-08	болт


№	Артикул	Наименование
10	278-51201-01	корпус вентилятора Yellow
40	011-00600-30	болт
60	277-52711-21	дроссель
61	277-52702-03	защита цилиндра
80	001-04061-60	болт
81	011-00600-20	болт
220	011-00600-10	болт
210	278-50201-30	стартер обратный
210	278-50201-20	стартер обратный
-1	270-50115-08	спиральная пружина
-2	269-50120-08	шкив
-3	282-50111-18	шнур
-4	261-50100-08	ручка стартера

Топливоснабжение EX21



№	Артикул	Наименование
30	043-04400-50	крышка Т.Б.
40	X64-13600-10	сетка топливная
48	050-51200-20	топливный фильтр
48	X50-51200-20	топливный фильтр
63	011-00601-30	болт
70	279-62602-11	топливная труба
90	056-11000-30	зажим Т.Т.
224	277-43801-01	рычаг крана


Карбюратор EX21



№	Артикул	Наименование
210	278-62301-30	Карбюратор Foam
210	278-62301-00	Карбюратор Foam
210	278-62302-30	Карбюратор Dual Element
210	278-62304-40	Карбюратор Low Profile
-1	277-62535-08	дроссельная заслонка
-2	209-62351-08	ВИНТ
-3	277-62525-08	воздушная заслонка Foam, Dual
-3	277-62527-08	воздушная заслонка Low Profile
-5	278-62420-08	жиклер холостого хода
-8	277-62520-08	вал воздушной заслонки Foam, Dual
-8	277-62520-08	вал воздушной заслонки Low Profile
-11	277-62531-18	вал дроссельной заслонки Dual, Cyclone

-12	227- 62451- 08	болт	-44	106- 62411- 08	воздушный жиклёр
-14	277- 62500- 08	игольчатый клапан	-45	106- 62410- 08	воздушный жиклёр
-15	277- 62515- 08	ось поплавка	-62	236- 62680- 08	манжет
-16	277- 62506- 08	поплавковая камера	-79	236- 62541- 08	уплотнитель
-17	214- 62450- 08	уплотнительная шайба	-102	246- 62390- 08	манжет
-18	214- 62540- 08	уплотнительное кольцо	-144	277- 62553- 08	гайка
-19	226- 62506- 08	поплавок	-300	279- 62103- 20	топливный кран
-20	278- 62440- 08	главный топливный жиклёр	-302	277- 62110- 18	уплотнитель
-22	277- 62406- 08	главный жиклёр Foam	-303	277- 62100- 18	отстойник
-22	277- 62405- 08	главный жиклёр Dual	-325	277- 62552- 08	топливный манжет
-24	226- 62701- 08	стопор	-327	165- 62377- 08	винт
-28	277- 62360- 08	пробка поплавковой камеры			
-40	106- 62556- 08	регулируемый винт			
-41	283- 62357-	пружина			

Электрическое устройство EX21




№	Артикул	Наименование
10	278-79240-21	маховое колесо STD
11	277-79431-11	катушка зажигания MARK BM3790
30	001-14062-50	болт
50	277-73101-H1	привод датчика мас.
70	015-00400-90	винт (саморез)
100	065-01401-50	свеча зажигания NGK BR6HS
110	065-50002-70	колпачок свечи зажигания
700	277-76301-21	масляный датчик
705	KU3-11071-01	выключатель
740	001-14061-60	болт
780	056-90000-20	зажим проводов


Картер двигателя EX27

№	Артикул	Наименование
10	279-10102-21	картер двигателя W/OIL SENSOR
20	237-14202-03	направляющая клапана
26	277-16010-01	сальник клапана
30	044-03001-60	сальник коленвала
40	060-03003-41	подшипник коленвала
50	277-15011-03	направляющая втулка
60	010-50802-50	шпилька
70	010-50604-10	шпилька
75	044-00600-20	сальник вала регулятора
80	040-11400-30	сливная пробка
90	021-11400-20	прокладка с.п.
210	279-11002-11	крышка главного подшипника
220	044-03001-60	сальник коленвала
230	060-03003-41	подшипник коленвала
250	277-45004-J1	шестерня регулятора
260	205-41901-03	ось шестерни регулятора
270	279-63601-23	масляный шуп
275	279-65001-03	пробка заливной горловины
280	021-32000-50	прокладка шупа
281	021-32000-50	прокладка пробки З.Г..
300	001-04083-50	болт крышки гл.подшипника
610	279-13001-11	головка цилиндра (ГБЦ) Old Style
620	279-15001-33	прокладка ГБЦ
630	011-00802-40	болт ГБЦ
631	001-04083-50	болт
680	277-15503-01	клапанная крышка

690	277-16001-13	прокладка клапанной крышки
700	277-15011-03	направляющая втулка
710	011-00600-20	болт к.к.
	279-99001-27	набор прокладок




Коленчатый вал и поршень EX27




№	Артикул	Наименование
10	279-20901-21	коленвал DU 25.4
10	279-21201-31	коленвал DH22.1Dx1/53
50	018-01800-10	гайка коленвала
70	032-30300-10	шпонка
310	279-22501-30	шатун в сборе
320	279-23001-03	болт крышки шатуна
350	279-23301-13	поршневой палец
360	279-23401-H3	поршень STD
361	279-23403-H3	поршень 0.25mm
362	279-23404-H3	поршень 0.50mm
370	279-23511-17	кольца поршневые STD
371	279-23512-17	кольца поршневые 0.25mm
372	279-23513-17	кольца поршневые 0.50mm
380	056-51800-10	стопорное кольцо


Глушитель, воздушный фильтр EX27




URETHANE FOAM



DUAL ELEMENT




PRE CLEANER



№	Артикул	Наименование
10	279-31601-01	Шестерня распредвала
25	277-35101-03	ось распредвала
27	024-00600-10	стопор
34	277-38601-03	ось пружины
35	279-36401-03	стопор
37	277-36501-03	шайба
38	277-38701-03	пружина
60	279-33601-03	пружина клапана
70	269-33701-03	чашка клапана
80	279-33401-H3	впускной клапан
90	279-33501-H3	выпускной клапан
95	132-10KA0-31	фиксатор клапана
150	279-35601-11	цепь ГРМ

			340	277-35201-13	прокладка глушителя
160	277-36911-03	натяжитель цепи			
			350	980-20082-80	гайка
163	277-37101-03	пружина натяжителя			
			360	015-20600-90	болт
166	277-36902-03	ось натяжителя			
			361	011-00600-10	болт
170	277-36913-13	успокоитель цепи			
			365	011-00801-50	болт
200	277-35002-01	ось рокера			
			387	015-00400-60	болт крепления дефлектора
202	003-13050-00	стопорное кольцо			
			440	277-37001-H1	дефлектор
220	277-36101-00	рокер впускного клапана			
			540	279-32902-J1	изолятор
225	277-36102-00	рокер выпускного клапана			
			550	279-35901-23	прокладка изолятора
230	014-90500-20	рег. винт рокера			
			570	002-38060-00	гайка
240	017-00500-30	контргайка Р.В.			
			850	085-10800-00	шланг сопла
290	011-00600-20	болт			
			580	011-00600-50	болт
310	279-30101-L1	глушитель			
			510	279-32613-50	воздушный фильтр в сборе
320	279-34201-31	крышка глушителя			
			-200	279-	нижняя часть


Механизм акселератора EX27




№	Артикул	Наименование
10	279-42301-13	рычаг вала регулятора
20	277-42201-33	вал регулятора
30	279-42701-11	тяга
40	277-42801-23	пружина регулятора
50	003-13050-00	стопор
60	013-00602-40	болт
18	018-60600-20	гайка
80	279-42502-23	пружина
310	279-43302-01	рычаг регулятора
322	277-43701-01	связующий стержень
340	277-43502-03	ограничитель регулятора
350	020-00601-70	фиксирующая шайба
355	021-	фрикционная

	70600-70	шайба
360	014-00601-80	регулируемый болт
365	237-45004-23	пружина
395	277-43901-03	фиксатор троса
396	004-36051-60	болт Ф.Т.
435	279-46009-01	платформа регулятора
440	004-31040-80	болт
450	002-35060-00	гайка
480	267-45101-03	пружина
485	011-00600-20	болт

Охлаждение и стартер EX27




RESIN




№	Артикул	Наименование
10	279-51201-01	корпус вентилятора Yellow
40	011-00600-30	болт
60	279-52711-11	дроссель
61	279-52702-03	защита цилиндра
80	001-65081-20	болт
81	011-00600-20	болт
220	011-00600-10	болт
210	279-50202-00	стартер обратный
-6	226-50731-08	фрикционная пружина
-7	226-50752-08	возвратная пружина
-8	226-50741-08	направляющая трещ
-11	279-50145-18	стакан стартера
-49	226-50753-08	болт
-1	226-50716-08	спиральная пружина
-2	279-50120-08	шкив
-3	279-50110-08	шнур
-4	226-50701-08	ручка стартера
-5	279-50125-08	трещотка

Топливоснабжение EX27



№	Артикул	Наименование
10	279-60101-11	топливный бак 6.1L — Yellow
30	043-04400-50	крышка Т.Б.
40	X64-13600-10	сетка топливная
48	050-51200-20	топливный фильтр
48	X50-51200-20	топливный фильтр
60	002-38080-00	гайка
63	011-00802-50	болт
70	279-62602-11	топливная труба
90	056-11000-30	зажим Т.Т.
224	277-43801-01	рычаг крана

Карбюратор EX27



№	Артикул	Наименование
210	279-62301-40	Карбюратор
-1	279-62535-08	дроссельная заслонка
-2	251-62450-08	винт
-3	279-62525-08	воздушная заслонка
-5	279-62420-08	жиклер холостого хода
-8	279-62520-08	вал воздушной заслонки
-11	279-62530-08	вал дроссельной заслонки
-12	251-62453-08	болт
-14	279-62500-08	игольчатый клапан
-15	279-62515-08	ось поплавка
-16	279-62550-08	поплавковая камера
-17	251-62350-08	уплотнительная шайба
-18	279-	уплотнительное

	62540-08	кольцо
-19	279-62505-08	поплавок
-22	279-62400-08	главный жиклёр
-24	226-62701-08	стопор
-28	279-62355-08	пробка поплавковой камеры
-40	279-62353-08	регулировочный винт
-41	283-62357-08	пружина
-41	210-62318-08	пружина
-300	279-62103-20	топливный кран
-302	064-20064-10	уплотнитель
-303	064-20078-10	отстойник
-325	277-62552-08	топливный манжет
-327	165-62377-08	винт

This exploded view diagram illustrates the assembly of a vehicle's rear suspension and steering components. The central element is a large, irregularly shaped frame or chassis section. Various parts are shown being installed onto this frame:


- Top Left:** A bracket (70,72) is shown being attached to the frame (60,61).
- Top Right:** A circular component (20) is shown being installed onto a larger, flange-like part (10).
- Middle Left:** A bracket (71) is shown being attached to the frame.
- Middle Right:** A bracket (40) is shown being attached to a component (23), which is then being installed onto the frame (12).
- Bottom Left:** A bracket (65) is shown being attached to the frame.
- Bottom Center:** A bracket (100) is shown being attached to the frame.
- Bottom Right:** A bracket (30) is shown being attached to a component (35,36), which is then being installed onto the frame (11).
- Far Bottom Right:** A bracket (15) is shown being attached to a component (110), which is then being installed onto the frame (112).

№	Артикул	Наименование
10	279-79230-01	маховое колесо STD
11	279-79430-01	катушка зажигания
30	001-14062-50	болт
50	277-73101-H1	привод датчика мас.
60	X60-00004-20	выключатель
70	015-00400-90	винт (саморез)
100	065-01401-50	свеча зажигания NGK BR6HS
110	065-50002-70	колпачок свечи зажигания
700	277-76301-21	масляный датчик
705	KU3-11071-01	выключатель
740	001-14061-60	болт
780	056-90000-20	зажим проводов


Картер двигателя EX40

№	Артикул	Наименование
1003	20B-10102-21	картер двигателя
1020	044-03500-90	сальник
1021	060-03502-40	подшипник
1022	X60-01500-11	подшипник
1030	277-15011-03	направляющая втулка
1035	044-00800-10	сальник
1041	040-11400-30	пробка
1042	021-11400-20	прокладка
1103	20B-11002-11	крышка главного подшипника
1108	044-03500-90	сальник
1109	060-03502-40	подшипник
1110	X60-01500-11	подшипник
1115	20B-45003-01	шестерня регулятора
1120	277-41901-03	ось шестерни регулятора
1130	224-63601-01	щуп в сборе
1131	224-63601-03	щуп
1132	021-32000-50	прокладка
1140	011-00803-40	болт
1202	20B-13001-00	головка цилиндра
1211	010-50603-51	шпилька
1212	010-50802-90	шпилька
1213	132-07AA0-50	сальник клапана
1214	056-51000-50	фиксатор
1215	263-35341-03	шайба
1220	20B-15001-03	прокладка ГБЦ

1225	031-00600-20	направляющая
1230	011-01000-40	болт
1231	001-04083-50	болт
1302	20B-15501-01	клапанная крышка
1330	20B-16001-03	прокладка
1335	011-00600-20	болт
1401	20B-14202-03	направляющая клапана
1501	20B-99001-07	набор прокладок








Коленчатый вал и поршень EX40



№	Артикул	Наименование
2003	20В-20901-01	коленвал
2030	005-32054-01	шпонка
2102	20В-22501-00	шатун в сборе
2105	001-05084-00	болт
2215	263-23301-33	поршневой палец
2220	056-52100-20	стопор
2402	20В-24101-03	балансирующая шайба
2501	20В-23401-Н3	поршень, std
2502	20В-23403-Н3	поршень, 0.25
2503	20В-23404-Н3	поршень, 0.5
2601	20В-23501-07	кольца поршневые, std
2602	20В-23502-07	кольца поршневые, 0.25
2603	20В-23503-07	кольца поршневые, 0.5


Глушитель, воздушный фильтр EX40



№	Артикул	Наименование
3002	20В-31601-00	распредвал
3005	005-19041-00	ось пружины
3007	277-36401-03	рычаг
3008	277-38702-03	пружина
3009	20В-36501-03	шайба
3020	20В-35101-11	ось распредвала
3022	024-00700-20	уплотнительное кольцо
3025	011-00600-20	болт
3030	20В-33401-Н3	впускной клапан
3032	20В-33501-Н3	выпускной клапан
3035	246-33611-03	пружина клапана
3036	246-33711-13	тарелка клапана
3038	246-35501-03	стопор клапана

3040	20В- 36101- 00	рокер	3102	20В- 30101- J2	глушитель
3043	014- 90500- 20	регулировочный винт	3111	20В- 34201- 11	крышка глушителя
3044	017- 00500- 30	контргайка	3115	267- 37101- 12	искрогаситель
3050	20В- 36102- 10	рокер	3118	015- 00400- 60	винт
3053	014- 90500- 20	регулировочный винт	3120	20В- 35201- 03	прокладка глушителя
3054	017- 00500- 30	контргайка	3125	011- 00600- 10	болт
3060	20В- 35001- 01	ось рокера	3126	980- 20082- 80	гайка
3063	003- 13060- 00	стопор	3127	011- 00803- 20	болт
3070	20В- 35601- Н1	цепь	3302	20В- 32611- Н0	воздушный фильтр
3076	277- 36911- 03	натяжитель	3310	X85- 11001- 80	шланг вентиляции
3077	277- 37101- 03	пружина	3320	002- 38060- 00	гайка
3078	277- 36902- 03	ось натяжителя	3321	001- 04061- 60	болт
3080	277- 36913- 13	успокоитель	3401	20В- 32850- Н8	направляющая ось


Механизм акселератора EX40



№	Артикул	Наименование
4003	20В-42301-00	рычаг акселератора
4007	001-14062-50	болт с шайбой
4008	018-60600-20	гайка
4010	20В-42201-01	вал акселератора
4012	003-13060-00	стопор
4015	003-11080-00	шайба
4016	003-13060-00	стопор
4021	20В-42701-01	тяга
4025	20В-42801-13	пружина
4030	20В-42501-13	пружина
4104	20В-43301-01	регулятор оборотов
4120	20В-46001-21	платформа
4122	20В-	прокладка

	35903-03	
4131	227-45002-03	гровер
4131	227-45002-03	гровер
4132	227-43501-13	ограничитель
4133	021-70600-30	фрикционная шайба
4134	002-35060-00	фиксирующая гайка
4140	004-31061-80	винт
4141	002-27060-00	гайка
4145	011-60400-30	болт
4146	267-45101-03	пружина
4147	277-43902-03	фиксатор троса
4148	013-10500-30	винт с шайбой
4150	277-96107-03	лейбл
4180	011-00600-20	болт


Охлаждение и стартер EX40



№	Артикул	Наименование
5004	20В-51201-Н1	кожух вентилятора
5007	KU3-11076-01	датчик
5010	20В-73102-01	провод
5012	004-36041-20	винт с шайбой
5020	001-04061-60	болт
5102	20В-50301-00	ручной стартер
5110	073-20054-70	лейбл
5120	013-00602-81	болт с шайбой
5130	20В-55101-02	кронштейн стартера
5135	010-00804-40	болт
5136	010-00804-50	болт
5140	002-38060-00	гайка
5302	20В-	экран цилиндра

	52702- H1	
5310	011- 00600- 20	болт
5501	20В- 50145- 08	стакан стартера
5502	261- 50100- 08	рукоять
5503	20В- 50110- 08	приводной шнур
5504	20В- 50101- 08	винт
5505	161- 50150- 08	напрвляющая шайба
5506	227- 50135- 08	пружина трещетки
5507	227- 50131- 08	фрикционная пружина
5509	161- 50125- 08	трещетка
5508	277- 50155- 08	возвратная пружина
5511	20В- 50150- 08	корпус стартера
5510	20В- 50120- 08	ШКИВ

Топливоснабжение EX40




№	Артикул	Наименование
6004	20В-60102-01	топливный бак
6010	043-04300-60	крышка
6015	X64-13600-10	сетка
6020	267-62604-11	топливопровод
6021	X85-10614-91	шланг
6023	X56-11100-60	хомут
6024	056-11200-40	хомут
6030	20В-95101-03	лейбл
6040	011-00802-50	болт
6042	002-38080-00	гайка
6050	073-20051-81	лейбл
6111	X64-20122-00	топливный кран
6115	20В-62601-01	топливопровод

6116	085-10620-90	хомут
6117	056-11000-30	хомут
6120	011-00600-20	болт
6125	056-81200-10	фиксатор
6130	20В-32901-J1	изолятор
6132	20В-35901-H3	прокладка
6133	20В-35902-H3	прокладка


Карбюратор EX40

№	Артикул	Наименование
6400	20В-62301-10	карбюратор
6402	20В-62353-08	регулировочный винт
6403	261-62352-08	винт заслонки
6404	20В-62453-08	винт
6405	20В-62535-08	дросельная заслонка
6406	20В-62526-08	воздушная заслонка
6407	226-62580-08	штулка вала
6408	258-62554-08	штулка вала
6409	263-62515-08	ось поплавка
6410	20В-62541-08	уплотнитель
6411	20В-62540-08	уплотнительное кольцо
6413	20В-62520-08	прокладка
6414	20В-62445-08	пружина



6415	20В-62505-08	поплавок
6416	20В-62500-08	игольчатый клапан
6417	20В-62527-18	вал воздушной заслонки
6418	20В-62530-08	вал дросельной заслонки
6419	20В-62420-08	ограничитель топлива
6420	20В-62400-08	манжет
6421	20В-62542-08	манжет
6422	20В-62550-08	поплавковая камера
6423	20В-62354-08	сливной винт
6424	20В-62357-08	регулятор топлива

Электрическое устройство EX40



№	Артикул	Наименование
7004	20В-79242-J1	маховик
7006	20В-79303-J1	катушка доп.электрооборудования
7011	20В-79430-H1	катушка зажигания
7012	065-50003-11	колпачёк свечи
7020	001-14063-00	болт с шайбой
7025	20В-54101-H3	вентилятор
7030	018-01800-10	гайка
7032	004-35062-00	винт с шайбой
7120	065-01401-50	свеча зажигания
7126	20В-73101-01	провод
7135	214-79006-01	зажим
7140	011-00600-10	болот
7202	279-76301-51	датчик масла

7203	277- 75801- 03	кронштейн	7403	20В- 75101- 01	кронштейн выключателя
7210	013- 00602- 60	болт с шайбой	7343	056- 60002- 50	зажим
7220	20В- 75501- 03	зажим	7405	066- 00003- 30	выключатель
7225	015- 20600- 50	болт	7415	073- 20044- 70	лейбл
7305	214- 79007- 01	болт	7420	277- 73103- 11	электро провода
7307	003- 10080- 00	шайба	7421	277- 73104- 01	электро провода
7315	003- 10080- 00	лейбл	7422	277- 73105- 01	электро провода
7331	20В- 76511- 01	кронштейн	7423	20В- 73105- 01	электро провода
7335	267- 71901- 11	регулятор	7425	056- 30000- 60	хомут
7336	056- 60002- 50	зажим	7430	013- 50600- 10	болт с шайбой
7338	011- 00600- 50	болт			
7340	20В- 73104- 01	электро провода			
7345	011- 00600- 20	болт			

Архангельск (8182)63-90-72	Иваново (4932)77-34-06	Магнитогорск (3519)55-03-13	Пермь (342)205-81-47	Сургут (3462)77-98-35
Астана (7172)727-132	Ижевск (3412)26-03-58	Москва (495)268-04-70	Ростов-на-Дону (863)308-18-15	Тверь (4822)63-31-35
Астрахань (8512)99-46-04	Иркутск (395)279-98-46	Мурманск (8152)59-64-93	Рязань (4912)46-61-64	Томск (3822)98-41-53
Барнаул (3852)73-04-60	Казань (843)206-01-48	Набережные Челны (8552)20-53-41	Самара (846)206-03-16	Тула (4872)74-02-29
Белгород (4722)40-23-64	Калининград (4012)72-03-81	Нижний Новгород (831)429-08-12	Санкт-Петербург (812)309-46-40	Тюмень (3452)66-21-18
Брянск (4832)59-03-52	Калуга (4842)92-23-67	Новокузнецк (3843)20-46-81	Саратов (845)249-38-78	Ульяновск (8422)24-23-59
Владивосток (423)249-28-31	Кемерово (3842)65-04-62	Новосибирск (383)227-86-73	Севастополь (8692)22-31-93	Уфа (347)229-48-12
Волгоград (844)278-03-48	Киров (8332)68-02-04	Омск (3812)21-46-40	Симферополь (3652)67-13-56	Хабаровск (4212)92-98-04
Вологда (8172)26-41-59	Краснодар (861)203-40-90	Орел (4862)44-53-42	Смоленск (4812)29-41-54	Челябинск (351)202-03-61
Воронеж (473)204-51-73	Красноярск (391)204-63-61	Оренбург (3532)37-68-04	Сочи (862)225-72-31	Череповец (8202)49-02-64
Екатеринбург (343)384-55-89	Курск (4712)77-13-04	Пенза (8412)22-31-16	Ставрополь (8652)20-65-13	Ярославль (4852)69-52-93
Липецк (4742)52-20-81				

Киргизия (996)312-96-26-47 Казахстан (772)734-952-31 Таджикистан (992)427-82-92-69